

MITSUBISHI STOJANY

	<p>STOJAN A383T25570 / -26170 / -28970 / -29370 / -31270 / -31470 / -40870 / -41870 / -49470</p> <p><u>Zastosowanie :</u> A2T30271, A5T30574</p>	<p>IA6148</p>
	<p>STOJAN A383T24970 / -25970 / -27570 / -28070 / -28270 / -29570 / -29670 / -30070 / -30270 / -30370 / -30570 / -31170 / -31870 / -31970 / -32170 / -32270 / -32370 / -32470 / -32570 / -33270 / -34970 / -37670 / -40570 / -48670 / -48770</p> <p><u>Zastosowanie :</u> A2T03591, -05892, -41791, -45272, -46492, -48176</p>	<p>IA6149</p>
	<p>STOJAN A383T34770, A383X54370</p> <p><u>Zastosowanie :</u> A2T08394, -13894, -14694, -18792, -27594, -29494</p>	<p>IA6150</p>
	<p>STOJAN 23102-05E16, A83T15770, A83T23070, MD607383</p> <p><u>Zastosowanie :</u> A3T35278</p>	<p>IA6162</p>
	<p>STOJAN 23102-36N10, 3735032120, A383T38170 / 38770 / 42170 / 46270 / 46670 MD618209, MD618657</p> <p><u>Zastosowanie :</u> A2T09591, -13977, -17574, -18177, -18277, -18874, -19991, -29594, -33191, -33493, -33991, -34477, -35177</p>	<p>IA6163</p>
	<p>STOJAN A383T46070, MD618718</p> <p><u>Zastosowanie :</u> A2T38291, -39991, -39992, -80591, -80592, A2TA4391, -5291, -5391</p>	<p>IA6164</p>

Nazwy i numery oryginalne użyte zostały wyłącznie jako propozycja zamienników