

## VALEO WIRNIKI ALTERNATORÓW & STOJANY

	<p>WIRNIK 593150, 593146, 593356</p> <p><u>Zastosowanie :</u> A11VI 28,-31, -54, -59, -61, -67, -76, -77, -79, -81, -85,- 87, -92, -93, -9496, -98, -104, -105</p>	<p><b>IA6000</b></p>
	<p>WIRNIK 593147, 593325, 2590941</p> <p><u>Zastosowanie :</u> A13VI 73, -94, -101, -118, -140, -142</p>	<p><b>IA6001</b></p>
	<p>WIRNIK 593274</p> <p><u>Zastosowanie :</u> A14VI 10, -11, -13, -14</p>	<p><b>IA6002</b></p>
	<p>STOJAN 592834/593279</p> <p><u>Zastosowanie :</u> A11VI11, -17, -18, -21, -22, -23, -25, -26, -28, -29, -30, -31, -32, -35, -36, -40, -43, -44, -45, -46, -48, -49, -51, -52, -54, -55, -56, -57, -59, -61, -62, -64, -66, -67, -76, -77, -79, -81, -82, -85, -86, -87, -88, -92, -93, -94, -95, -96, -97, -104, -105</p>	<p><b>IA6100</b></p>
	<p>STOJAN 592832, 593154, 593160, 593334</p> <p><u>Zastosowanie :</u> A13VI 11, -13, -17, -18, -21, -25, -28, -30, -32, -34, -35, -45, -47, -52, -67, -68, -70, -77</p>	<p><b>IA6101</b></p>
	<p>STOJAN 593159</p> <p><u>Zastosowanie :</u> A14VI 10, -11, -13, -14</p>	<p><b>IA6102</b></p>

Nazwy i numery oryginalne użyte zostały wyłącznie jako propozycja zamienników

**TPA POLSKA sp.z o.o.** – ul. Świętokrzyska 45 – 80-180 Gdańsk - Polska

Tél. : + 48 58 304 79 51

Fax : + 48 58 304 72 36